

CHAPTER 88

AIRCRAFT, SPACECRAFT, AND PARTS THEREOF

ANNOT
ATION

SUBHEADING NOTE:

1. For the purposes of subheadings No. 8802.11 to 8802.40, the expression "unladen weight" means the weight of the machine in normal flying order, excluding the weight of the crew and of fuel and equipment other than permanently fitted items of equipment. **A/S.0001**

